



List of Tables

Table 2-1	Transmission Frequency Channels	2-3
Table 2-2	Power Settings	2-4
Table 2-3	Class C Subnetting	2-7
Table 2-4	Usable Host Addresses	2-8
Table 2-5	RIP Routing Table for Datagrams Sent from a Host on Network C	2-11
Table 2-6	Blank Configuration Worksheet	2-13
Table 2-7	Sample Completed Configuration Worksheet	2-14
Table 3-1	Service Console Key Sequences	3-7
Table 3-2	Telnet Connection Key Sequences	3-8
Table 4-1	TALnet Monitoring Commands	4-2
Table 4-2	Received Signal Strength (RSS)	4-6
Table 4-3	UDP Packet Generator Keys	4-8
Table 4-4	UDP Packet Receiver Keys	4-9
Table A-1	TALnet Commands	A-1
Table A-2	Transmission Frequency Channels	A-106
Table A-3	Power Settings	A-107
Table A-4	Received Signal Strength (RSS)	A-113
Table A-5	Navigating through a File View	A-135
Table C-1	Moving the Cursor in Command Mode	C-2
Table C-2	Modifying the File in Command Mode	C-3
Table C-3	Saving and Exiting the File	C-3

