Linking BPQ Switches via Ethernet.

By Bill Barnes. N3JIX

Brief technical description: Two or more computers, running G8BPQ node software. There is a need to link all these switches together. There are two options: a 9600 baud RS-232 kiss port, or a Ethernet port. BPQ wrote a driver for ODT that will allow the switch to talk to Ethernet. This is a document on that process.


Key Words: G8BPQ, Ethernet, ODI.

What is ODI?

ODI is Novell's newest idea for Clients. Before, when you changed cards, you had to change IPX versions as well. Also, that old IPX wasn't as "flexible" on card settings either. So, Novell decide to make a flexible IPX, and well, it grew way over that, into ODI. What ODI allows is card manufactures to write a driver for their card, and use a generic IPX. So, the only thing that need to be changed is the card driver and edit the section in the NET.CFG file.

ODI depends on a Link Support Layer or LSL. This file always needs to be loaded first, LSL.COM.

Here is a diagram of how ODI works. and how G8BPQ's driver fits in there.



Does that make any sense? No? Well, the idea is that many network cards can talk to LSL, and many protocols can talk to LSL. So LSL is kinda like a traffic cop.

Ok, Here's how to make it work.

My AUTOEXEC.BAT:

@echo off	
prompt \$p\$q\$g	
cd\network	
lsl	: LSL is always neededfirst.
ne2000	; This is your card driver.
cd\bpq	
odidrv 125	; This is your External ODI drv for BPQ.
	; 125 is the Intlevel from your Ports section.
bpqcode	, Of course, BPQCODE and anything else
	; you may need to load.
cdl	
ipxodi	; IPX is only neededfor Novell. Optional
	; IPXODI needs to be loaded after ODIDRV
	; To Avoid Lock up problems later

My NET.CFG:

Link Driver NE2000	Your driver section.
PORT 280	Your I/O address for card.
INT 12	Your IRQ address for card.
FRAME Ethernet_802.2	Frame for Novell. Optional
FRAME ETHERNET II	Frame for BPQ.
PROTOCOL IPX 0 ETHERNET 802.2	Needed for Novell Optional
PROTOCOL BPQ 8FF ETHERNET_II	Needed for BPQ
BPQPARAMS ; BH	PQ Driver info
ETH_ADDR FF:FF:FF:FF:FF	; Set to broadcast to sense all

; nodes. If you change that to the other card's Ethernet address, it should be faster, and ; generate less traffic on a LAN. I use the broadcast because the LAN is just for BPQ.

My PORT section of BPQCFG.TXT:

ID=Ethernet Port TYPE=EXTERNALThis is an external driverPROTOCOL=KISSKISS or Netrom, both should work. I triedINTLEVEL=125KISS only. (Note: $0x96=125$)SPEED=9600Should Not be needed.CHANNEL=AShould Not be Needed.QUALITY=203, Netrom quality for this port.MAXFRAME=7;Send as many frames as possible becauseTXDELAY=0, of a dedicated high speed link.SLOTTIME=100No need to wait for other stations, wire link.
PROTOCOL=KISSKISS or Netrom, both should work. I triedINTLEVEL=125KISS only. (Note: $0x96=125$)SPEED=9600Should Not be needed.CHANNEL=AShould Not be Needed.QUALITY=203, Netrom quality for this port.MAXFRAME=7;Send as many frames as possible becauseTXDELAY=0, of a dedicated high speed link.SLOTTIME=100
INTLEVEL=125KISS only. (Note: $0x96=125$)SPEED=9600Should Not be needed.CHANNEL=AShould Not be Needed.QUALITY=203,Netrom quality for this port.MAXFRAME=7;Send as many frames as possible becauseTXDELAY=0,of a dedicated high speed link.SLOTTIME=100,
SPEED=9600Should Not be needed.CHANNEL=AShould Not be Needed.QUALITY=203, Netrom quality for this port.MAXFRAME=7;Send as many frames as possible becauseTXDELAY=0, of a dedicated high speed link.SLOTTIME=100, of a dedicated high speed link.
CHANNEL=A QUALITY=203 TXDELAY=0 SLOTTIME=100Should Not be Needed. , Netrom quality for this port. , Netrom quality for this port. , Send as many frames as possible because , of a dedicated high speed link.
<i>QUALITY=203</i> <i>MAXFRAME=7</i> <i>TXDELAY=0</i> <i>SLOTTIME=100</i> <i>MAXFRAME = 100</i> <i>Metrow quality for this port.</i> <i>Send as many frames as possible because</i> <i>of a dedicated high speed link.</i>
MAXFRAME=7 TXDELAY=0 SLOTTIME=100;Send as many frames as possible because , of a dedicated high speed link.
TXDELAY=0 , of a dedicated high speed link. SLOTTIME=100
SLOTTIME=100
PERSIST=255 No need to wait for other stations, wire link.
FULLDUP=1
FRACK=7000
RESPTIME=100

Run BPQCFG, try the drivers by hand, and make sure they work before rebooting. Most common problems are wrong setting for the network card in the NET.CFG or something spelled wrong in NET.CFG.

Where to Get it:

G8BPQ 4.08a: Internet URL: ftp://ftp.tapr.org/tapr/software_lib/switch/bpq408a.zip Other Sources: Unknown.

ODI Drivers for Use in this project:

Internet URL: ftp://ftp.novell.com/pub/updates/nwos/dscInt 12/vlmkt* .exe ** Where vlmkt* exe = vlmkt1 .exe through vlmkt6.exe ** These are the install disks for Novell Dos Client.

Resources Used: (Reference List...)

G8BPQ, "G8BPQ's DRIVERS.DOC" from Version 4.08A of the software. J. Chellis, R. Easlick, M. Moncur, A. Olsen, J. Tanner,"The CNE-4 Study Guide," SYBEX Books, 1996.